

Planning documents

Partial waterproofing system (OS 10)

# Triflex Crack Dressing



# Triflex Crack Dressing



## Applications



The **Triflex Crack Dressing** is a fleece-reinforced waterproofing system for the repair of parking decks, to be used as a local measure for the waterproofing of moving separation cracks, areas at risk of cracks and construction joints. The system is made of fast-curing polymethylmethacrylate resins (PMMA) and has been specially designed for multi-storey car park traffic. It can be used as a permanent waterproofing system that withstands high mechanical loads but also as a quick temporary solution in order to reliably protect the structure from penetrating moisture. The partial waterproofing system **Triflex Crack Dressing** has a General Building Supervisory Authority Test Certificate (abP) and is classified to OS 10 of the Repair Guideline (RiLi-SIB).

### Quick partial refurbishment for low budgets

In addition to mechanical loads as a result of multi-storey car park traffic, thermal and dynamic movements also place heavy demands on multi-storey car park structures. The OS 8 surface protection that is mostly used for cost reasons often fails to meet these demands on a long-term basis. This results in the formation of cracks. The ingress of moisture and de-icing salts can then lead to corrosion, which can endanger the structural stability of the building over the long-term.

The **Triflex Crack Dressing** system is a cost-effective alternative to the full-surface refurbishment of damaged foundation slabs. The dressing can be applied as a long-lasting solution with surface-level mounting and filled stop cuts, or alternatively as a surface construction, in both cases with an abrasion-resistant wearing layer. The fleece-reinforced waterproofing system is also suitable for use as a temporary solution for the quick repair of the structure. Refurbished surfaces can be driven on again after just a few hours.



## Advantages at a glance

### Dynamic crack-bridging properties

The system is full-surface fleece-reinforced. This gives the material a level of flexibility that leaves it unaffected by any movement of the foundation. Triflex Crack Dressing meets the maximum crack-bridging capability in accordance with OS 10 Repair Guideline (RiLi-SIB) with increased dynamic crack-bridging in Class B 4.2 (-20°C).

### Long-lasting protection

The Triflex Crack Dressing system withstands high mechanical loads, which extends refurbishment intervals by years. The surfacing solution Triflex Cryl M 264 meets the strictest requirements of the German Federal Highway Research Institute (BASt) – Traffic Class P 7 according to DIN EN 13197. This classification is based on a wear test of 4 million cycles. Tests of the protective and wearing layer prove a functional capability of 8 million cycles.

### Short closure periods

Triflex Crack Dressing offers much faster curing times than systems made of PUR resins. Refurbishments in traffic-sensitive areas such as entrances and exits can be performed in just a few hours thanks to the optimised application time. This safeguards income and reduces closure times and disruptions to traffic. Parking spaces are soon ready for use again.

### Long-lasting and robust

The shear-resistant chemical bond in all layers helps to prevent delamination. The low-maintenance system is suitable for a range of different substrates. Triflex Crack Dressing is a weather-proof system that is resistant to de-icing salt, and protects against the ingress of harmful substances.

### Ideal for refurbishments

The partial waterproofing of damaged areas can be performed quickly and cost-effectively. The non-slip surfacing solution is available in a range of colours so can be selected to match old coatings. This helps to limit the cost of refurbishment.

### Certified safety

The Triflex Crack Dressing system has obtained a Class OS 10 General Building Supervisory Authority Test Certificate (abP) in accordance with the Building Regulations List A, Part 2, No. 2.24 and VV TB Section C 3.12, Fire classification B<sub>fl</sub>-s1 in compliance with DIN EN 13501-1.



Partial waterproofing system (OS 10)

# Triflex Crack Dressing

And this is how it's done...



1. Mill out and grind the surface



2. Cut stops 10 cm to the left and right of the crack.



3. The surface is primed and stops and cracks are sealed.



4. Apply waterproofing resin Triflex ProPark and lay Triflex Special Fleece...



5. ... then apply a coating of Triflex ProPark wet-on-wet.



6. Then apply the Triflex Cryl M 264 wearing layer so it is flush with the surface.



7. Done! The surface is suitable for vehicle traffic again after 3 hours.



## Compatible system components

All the Triflex products mentioned in this system are lab-scale and application coordinated as a result of years of experience. This standard of quality ensures optimum results during both application and use.



Partial waterproofing system (OS 10)

# Triflex Crack Dressing

## System description

### Properties

- Full-surface reinforced waterproofing system based entirely on polymethyl methacrylate (PMMA)
- Withstands high mechanical loads
- Shear-resistant construction
- Seamless
- Full-surface adhesion and impermeable
- Elastic
- Enhanced dynamic crack-bridging, Class B 4.2 (-20 °C)
- Cold-applied
- Fast-curing
- Ready for vehicle traffic after approx. 3 hours
- Chemical-resistant, resistant to de-icing salt.
- Weather-resistant (UV, IR, etc.)
- Non-slip
- Variety of colours available
- Class OS 10 Building Supervisory Authority Test Certificate (abP) according to Building Regulations List A Part 2, No. 2.24 and VV TB, Section C 3.12, Fire classification B<sub>fl</sub>-s1 (flame-retardant) as per DIN EN 13501-1

### System versions and system build-up

#### Triflex Crack Dressing, version 1

Flush installation.


Crack Dressing in accordance with the DBV (German Society for Concrete and Construction Technology) good practice guide "Parkhäuser und Tiefgaragen" (multi-storey car parks and underground car parks) with OS 10 test certificate.

#### Triflex Crack Dressing, version 2

Construction with non-slip wearing layer. Crack Dressing without collision protection with OS 10 test certificate.

#### Triflex Crack Dressing, version 3

Construction without wearing layer. Crack Dressing without collision protection as a building waterproofing with Building Supervisory Authority Test Certificate [abP].



### System components

#### Primer

Triflex Primer for sealing the substrate and ensuring substrate adhesion (see Substrate pre-treatment table)

#### Waterproofing\*

Triflex ProPark reinforced with Triflex Special Fleece

#### Wearing layer\*\*

Triflex Ceryl M 264

Note: Term under "German Committee on Reinforced Concrete (DAfStb) – Guidelines for the protection and repair of concrete components" \* = sealing layer \*\* = protective and wearing layer

# Triflex Crack Dressing



## System description

### Substrate

Substrate suitability should always be checked on a case-by-case basis. The substrate must be clean, dry and free of cement bloom, dust, oil, grease and other adhesion-reducing dirt. The substrate must be pre-treated in accordance with the specifications in the Repair Guideline (Rili SIB). The following consumption specifications relate to a roughness depth of  $R_t = 0.5$  mm.

**Moisture:** When carrying out the work, the substrate moisture must not exceed 6 % by weight.

Ensure that structural measures are taken to prevent moisture penetration of the coating from underneath.

**Dew point:** During application, the surface temperature must be at least 3 °C above the dew point temperature. Below this temperature, a separating film of moisture can form on the surface.

**Hardness:** Mineral substrates must be permitted to fully harden for at least 28 days.

**Adhesion:** The following minimum tensile adhesion strengths must be met on pre-treated test areas:

Concrete: in the centre, at least 1.5 N/mm<sup>2</sup>, individual value not less than 1.0 N/mm<sup>2</sup>.

### Substrate pre-treatment

Substrate	Pre-treatment	Primer
Aluminium <sup>(1)</sup>	Remove loose rust and rust scale, abrade with Triflex Cleaner	Triflex Metal Primer <sup>(2)</sup>
Asphalt	Grinding, milling or dust-free shot-blasting	Triflex Cryl Primer 222
Concrete	Grinding, milling or dust-free shot-blasting	Triflex Cryl Primer 287
Copper <sup>(1)</sup>	Remove loose rust and rust scale, abrade with Triflex Cleaner	Triflex Metal Primer <sup>(2)</sup>
Epoxy resin coating	Roughen, expose granular structure, adhesive strength and compatibility test	No primer
Mortar, resin-modified	Grinding, milling or dust-free shot-blasting; adhesive strength and compatibility test	Triflex Pox Primer 116+
Paints	Grinding or milling, completely remove	See substrate
Plaster/masonry <sup>(1)</sup>		Triflex Cryl Primer 287
PU coating	Roughen, expose granular structure, adhesive strength and compatibility test	No primer
Screeds	Grinding, milling or dust-free shot-blasting	Triflex Cryl Primer 287
Stainless steel <sup>(1)</sup>	Remove loose rust and rust scale, abrade with Triflex Cleaner	Triflex Metal Primer <sup>(2)</sup>
Steel, galvanised <sup>(1)</sup>	Remove loose rust and rust scale, abrade with Triflex Cleaner	Triflex Metal Primer <sup>(2)</sup>
Tiles	Mechanically remove glaze	Triflex Cryl Primer 287
Zinc <sup>(1)</sup>	Remove loose rust and rust scale, abrade with Triflex Cleaner	Triflex Metal Primer <sup>(2)</sup>

<sup>(1)</sup> Only in areas not subject to high mechanical stress, e.g. details and flashing.

<sup>(2)</sup> Alternative to priming: Abrade with Triflex Cleaner, roughen surface.

Information on other substrates is available on request (technik@triflex.de).

**Important note:** Adhesion to the substrate must be checked on a case-by-case basis!

### Primer

#### Triflex Cryl Primer 222

Apply evenly with a Triflex universal roller.

Consumption: at least 0.40 kg/m<sup>2</sup>.

Can be recoated after approx. 45 min.

#### Triflex Cryl Primer 287

Pour on thickly and spread evenly using a cellular rubber spreader.

Then recoat crosswise using a Triflex universal roller.

Consumption: at least 0.35 kg/m<sup>2</sup>.

Can be recoated after approx. 45 min.

#### Triflex Metal Primer

Apply a thin coat with a short-pile roller or, alternatively, spray a thin coat with a spray can.

Consumption: approx. 80 ml/m<sup>2</sup>.

Can be recoated after approx. 30 to 60 min.

#### Triflex Pox Primer 116+

Pour on thickly and spread evenly using a cellular rubber spreader.

Then recoat using a Triflex universal roller.

Do not allow puddles to form.

Dress with not too much of the fresh primer.

Consumption of Triflex Pox Primer 116+: at least 0.30 kg/m<sup>2</sup>.

Consumption of quartz sand 0.3-0.8 mm: at least 0.70 kg/m<sup>2</sup>.

Can be recoated after approx. 12 hrs. to max. 24 hrs.

# Triflex Crack Dressing



## System description

### Repairing

#### In the case of roughness depths $R_t$ 0.5 to 1 mm:

Scratch coat for repairing mineral or bituminous substrates with the addition of up to 10 kg quartz sand 0.2–0.6 mm\* per 33 kg of Triflex DeckFloor.  
Consumption: at least 2.00 kg/m<sup>2</sup> per mm layer thickness.  
Can be recoated after approx. 1 hrs.

#### In the case of roughness depths $R_t$ 1 to 10 mm:

Levelling coat for repairing mineral or bituminous substrates with the addition of up to 20 kg quartz sand 0.7–1.2 mm\* per 33 kg of Triflex DeckFloor.  
Consumption: at least 2.00 kg/m<sup>2</sup> per mm layer thickness.  
Can be recoated after approx. 1 hrs.

#### In the case of roughness depths $R_t$ >10 mm:

##### Triflex Cryl RS 240

Mortar for repairing mineral substrates.  
Consumption: at least 2.20 kg/m<sup>2</sup> per mm layer thickness.  
Can be recoated after approx. 45 min.

##### Triflex Cryl RS 242

Mortar for repairing bituminous substrates.  
Consumption: at least 2.20 kg/m<sup>2</sup> per mm layer thickness.  
Can be recoated after approx. 1 hrs.

### Crack Dressing, version 1

#### Preparatory work:

The surface for the Crack Dressing must be abraded to a depth of approx. 5 mm, and then levelled out by grinding. In order to prevent the possibility of water infiltration, a stop is cut in the junction between the old coating and the Crack Dressing (see system drawings). This must have a depth of 5 mm underneath the embedded area on both sides. The stop must be cut before starting waterproofing work. Once the surface has been cleaned, the primer is applied and the crack and stop are filled. Any defects should be treated as repairs.

#### Sequence of steps:

1. Mark the surface for the Crack Dressing centrally above the crack.
2. Mill out and grind the surface
3. Cut stop
4. Prime the surface, sealing the stop and the crack
5. Apply the waterproofing
6. Apply the wearing layer

#### Waterproofing:

Application is wet-on-wet.

##### 1. Triflex ProPark

Apply evenly with a Triflex Universal Roller.  
Consumption: at least 2.00 kg/m<sup>2</sup>.

##### 2. Triflex Special Fleece

Lay fleece, removing any air bubbles. Overlap the strips of fleece by at least 5 cm.

##### 3. Triflex ProPark

Apply until the Triflex Special Fleece is fully saturated.  
Consumption: at least 1.00 kg/m<sup>2</sup>.

Total consumption of Triflex ProPark: at least 3.00 kg/m<sup>2</sup>.

Can be recoated after approx. 45 min.

For dimensions see system drawings.

#### Important note:

The area adjacent to the Crack Dressing is taped off with adhesive tape in order to create a clean joint. The adhesive tape must be removed before curing the waterproofing, and new tape applied for the wearing layer.

#### Wearing layer:

##### Triflex Cryl M 264

Apply evenly with a smoothing trowel and spread over the grain tips.

Consumption: at least 4.00 kg/m<sup>2</sup>.

Can be walked on after approx. 1 hr.

Ready for vehicle traffic after approx. 3 hrs.

#### Important note:

The "Triflex ProPark, version 2" system design has obtained a Class OS 10 General Building Supervisory Authority Test Certificate (abP) in accordance with the Building Regulations List A, Part 2, No. 2.24 and VV TB Section C 3.12, Fire classification B<sub>fl</sub>-s1 in compliance with DIN EN 13501-1. The Crack Dressing is designed based on the specifications in the DBV (German Society for Concrete and Construction Technology) good practice guide "Parkhäuser und Tiefgaragen" (multi-storey car parks and underground car parks), 2018 edition.

\* The quartz sand grading curve must be adjusted on site, if necessary.

# Triflex Crack Dressing



## System description

### Crack Dressing, version 2

#### Preparatory work:

A 20-cm-wide strip is marked centrally to the crack. The surface for the Crack Dressing is pre-treated by grinding and exposing the granular structure. Sufficient intermediate adhesion must be ensured.

#### Sequence of steps:

1. Mark the surface for the Crack Dressing centrally above the crack.
2. Grind the surface
3. Prime the surface (if necessary)
4. Apply the waterproofing
5. Apply the wearing layer

#### Waterproofing:

Application is wet-on-wet.

##### 1. Triflex ProPark

Apply evenly with a Triflex Universal Roller.  
Consumption: at least 2.00 kg/m<sup>2</sup>.

##### 2. Triflex Special Fleece

Lay fleece, removing any air bubbles. Overlap the strips of fleece by at least 5 cm.

##### 3. Triflex ProPark

Apply until the Triflex Special Fleece is fully saturated.  
Consumption: at least 1.00 kg/m<sup>2</sup>.

Total consumption of Triflex ProPark: at least 3.00 kg/m<sup>2</sup>.

Can be recoated after approx. 45 min.

For dimensions see system drawings.

#### Important note:

The area adjacent to the Crack Dressing is taped off with adhesive tape in order to create a clean joint. The adhesive tape must be removed before curing the waterproofing, and new tape applied for the wearing layer.

#### Wearing layer:

##### Triflex Cryl M 264

Apply evenly with a smoothing trowel and spread over the grain tips.

Consumption: at least 4.00 kg/m<sup>2</sup>.

Can be walked on after approx. 1 hr.

Ready for vehicle traffic after approx. 3 hrs.

#### Important note:

The "Triflex ProPark, version 2" system design has obtained a Class OS 10 General Building Supervisory Authority Test Certificate (abP) in accordance with the Building Regulations List A, Part 2, No. 2.24 and VV TB Section C 3.12, Fire classification B<sub>fl</sub>-s1 in compliance with DIN EN 13501-1.

In this version, the Crack Dressing has no collision protection and no permeation protection. If these properties are required, the Crack Dressing version 1 should be used.

### Crack Dressing, version 3

#### Preparatory work:

A 20-cm-wide strip is marked centrally to the crack. The surface for the Crack Dressing is pre-treated by grinding and exposing the granular structure. Sufficient intermediate adhesion must be ensured.

#### Sequence of steps:

1. Mark the surface for the Crack Dressing centrally above the crack.
2. Grind the surface
3. Prime the surface (if necessary)
4. Apply the waterproofing

#### Waterproofing:

Application is wet-on-wet.

##### 1. Triflex ProPark

Apply evenly with a Triflex Universal Roller.  
Consumption: at least 2.00 kg/m<sup>2</sup>.

##### 2. Triflex Special Fleece

Lay fleece, removing any air bubbles. Overlap the strips of fleece by at least 5 cm.

##### 3. Triflex ProPark

Apply until the Triflex Special Fleece is fully saturated.  
Consumption: at least 1.00 kg/m<sup>2</sup>.

Total consumption of Triflex ProPark: at least 3.00 kg/m<sup>2</sup>.

Can be recoated after approx. 45 min.

For dimensions see system drawings.

#### Important note:

The area adjacent to the Crack Dressing is taped off with adhesive tape in order to create a clean joint. The adhesive tape must be removed before curing the waterproofing.

#### Important note:

This waterproofing system has a General Building Supervisory Authority Test Certificate (abP) for building waterproofing in accordance with the Building Regulations List A, Part 2, No. 1.12 and VV TB Section C 3.28, Liquid-applied waterproofing of building structures.

The version 3 Crack Dressing is intended as a short-term solution in order to prevent the ingress of chloride into the structure. It is applied as a "plaster" without any collision protection or permeation protection and without a non-slip wearing layer above the waterproofing. If these properties are required, the Crack Dressing version 1 should be used.



Partial waterproofing system (OS 10)

# Triflex Crack Dressing

## System description

### Work interruptions

If work is interrupted for more than 12 hrs, or if soiled by rain etc., the intersection must be activated with Triflex Cleaner. Airing time at least 20 min. Transitions to subsequent waterproofing must overlap (including Triflex Special Fleece) by a minimum of 10 cm. This also applies to junctions, transitions and detail solutions with Triflex ProDetail. The finish must be applied within 24 hrs. If this application is delayed for any reason, the surface to be finished must be pre-treated with Triflex Cleaner.

### System components

For information on applications, conditions for use and instructions for mixing, see product information (request if necessary):

<b>Triflex Cleaner</b>	<b>Triflex DeckFloor</b>
<b>Triflex Cryl M 264</b>	<b>Triflex Liquid Thixo</b>
<b>Triflex Cryl Paste</b>	<b>Triflex Metal Primer</b>
<b>Triflex Cryl Primer 222</b>	<b>Triflex Pox Primer 116+</b>
<b>Triflex Cryl Primer 287</b>	<b>Triflex ProPark</b>
<b>Triflex Cryl RS 240</b>	<b>Triflex Special Fleece</b>
<b>Triflex Cryl RS 242</b>	

### Quality standard

All Triflex products are manufactured in accordance with the standards defined in ISO 9001. To ensure quality is not compromised, Triflex products are only installed by specialist, fully trained and qualified contractors.

### Gradient/Evenness

Before commencing any work and during the work itself, it is essential to ensure the correct gradient and evenness of the substrate. Any corrections required must be taken into account during this work.

### Dimensional tolerances

When carrying out the work, always ensure compliance with the permissible tolerances for building construction (DIN 18202, Table 3, line 4).

### Safety tips/Accident prevention

Read the safety data sheets before using the products.

### Required consumptions/Waiting times

The specified consumptions apply only to smooth, even substrates with a maximum roughness depth of  $R_t = 0.5$  mm. Special allowances must be made for unevenness, roughness and porosity. Information regarding airing and waiting times applies to a substrate at an ambient temperature of  $+20^\circ\text{C}$ .

### Application notes

Driving lane coatings are subject to constant loads and stresses in accordance with the level of use. The effects of UV light and weather as well as organic dyes (e.g. foliage) and various chemicals (e.g. disinfectants, acids, etc.) may cause discolouration, yellowing and chalking effects in finishes. Abrasion can scratch the surface. This does not affect the mechanical properties of the cured coating.

### General notes

The basis for the use of Triflex products can be found in the system descriptions, system drawings and product information sheets. It is essential to heed these when planning and carrying out the building project. Deviations from the technical information of Triflex GmbH & Co. KG applicable at the time of work can compromise the guarantee. Any project-related deviations are subject to the written authorisation of Triflex.

All data is based on general regulations, directives and other technical rules. The general regulations applicable in the particular country of use must be respected. Since the parameters can vary from case to case, the user is required to test the suitability, e.g. of the substrate.

Non-Triflex products must not be used with Triflex systems. Subject to change in the interests of technical advancement or enhancement of Triflex products.

### Tender texts

Please visit the Download section of the Triflex website at [www.triflex.com](http://www.triflex.com) to obtain the current standard specifications, which are available in a range of different file formats. Alternatively, visit the website [www.ausschreiben.de](http://www.ausschreiben.de) or [www.heinze.de](http://www.heinze.de).

### CAD drawings

All CAD system drawings can be downloaded free of charge from the Download section of the Triflex website at [www.triflex.com](http://www.triflex.com).




# Triflex Crack Dressing




## System drawings

Crack Dressing, version 1



Drawing no.: Crack Dressing-1001

System set-up – Detail A






Partial waterproofing system (OS 10)


# Triflex Crack Dressing

## System drawings

Crack Dressing, version 2



System set-up – Detail B




# Triflex Crack Dressing




## System drawings

Crack Dressing, version 3



System set-up – Detail C



## Triflex Crack Dressing surfaces

### Wearing layer with Triflex Cryl M 264



7030 Stone grey



7032 Pebble grey



7037 Dusty grey



7040 Window grey



7042 Traffic grey A



1023 Traffic yellow




2009 Traffic orange



3020 Traffic red



4006 Traffic purple



5017 Traffic blue



6024 Traffic green



7043 Traffic grey B



9010 White

### Triflex ProPark waterproofing



7030 Stone grey



7043 Traffic grey B

#### Note:

Minor variations between the colour shown here and the actual colour are due to printing technology and the materials used.

#### International

Triflex GmbH & Co. KG  
Karlstrasse 59  
32423 Minden | Germany  
Fon +49 571 38780-708  
international@triflex.com  
www.triflex.com

